


Neural Engineering Team Week.4

2022.11.04 6pm Lee Seong Jin


복습!!!



Sampling frequency : 1s를 몇 개의 point로 sampling 했냐?

복습!!!

• Sampling frequency : 1s를 몇 개의 point로 sampling 했냐?



21명의 피험자에게 3초간 'O' 20번, 'X' 80번을 보여주는 총 100번의 Event를 가함이 때 Sampling frequency는 200Hz 였고, 64개 채널(전극) 사용하여 EEG 기록

EEG의 shape은?

21 x 64 x 300 x 200 : 피험자 수×채널 수×총 시간(s) × Sampling frequency



21 x 64 x 100 x 3 x 200 : 피험자 수×채널 수×Trial 수×시간(s)×Sampling frequency




21 x 64 x 60000 : 피험자 수×채널 수×Trial 수×Sampling point 수 (점의 개수)

복습!!!

• 진동수(주파수 : Frequency) : 1s 동안 진동한 횟수


• 1s에 1번 왕복 운동 (진동) : 1Hz

• FFT (Fast Fourier Transform) : Signal을 Time domain에서 Frequency domain으로 변환




복습!!! <Filtering>


- Filtering : 필요로 하는 Signal을 제외한 불필요한 noise를 제거해주는 방법
- EEG의 경우 0.5Hz 이하, 100Hz 이상의 frequency 성분을 제거해주는 것이 일반적임
 → Low-Pass Filtering, High-Pass Filtering
- 전원 노이즈(60Hz 성분) 또한 제거 → Notch Filtering (Band-Stop Filtering)





복습!!! <Filtering>

- Filtering : 필요로 하는 Signal을 제외한 불필요한 noise를 제거해주는 방법
- EEG의 경우 0.5Hz 이하, 100Hz 이상의 frequency 성분을 제거해주는 것이 일반적임
 → Low-Pass Filtering, High-Pass Filtering
- 전원 노이즈(60Hz 성분) 또한 제거 → Notch Filtering (Band-Stop Filtering)











복습!!! Notch Filtering (Band-Stop)



복습!!! ERP (Event Related Potential)

ERP(사건관련전위)

: 실험자가 피험자에게 가한 Event(자극)에 대해서 발생한 뇌파(EEG)



Name

Positive peak voltage : P Negative peak voltage : N

Sequence: P1, P2, P3... / N1, N2, N3...

Timing: P300, N170, N400 ...


Waveform

- 1 Peak voltage amplitude
- 2 Latency
- Absolute latency

time interval between stimulus presentation and the point of maximal value (peak) of a defined component

- 1000 Relative latency (inter-peak latency) time interval between two components
 - 3 Event code (=Trigger code)

복습!!! Procedure of ERP acquisition



Data information

An 18-subject EEG data collection using a visual-oddball task, designed for benchmarking algorithms and headset performance comparisons

Kay Robbins, a,* Kyung-min Su, a and W. David Hairston b,*

► Author information ► Article notes ► Copyright and License information <u>Disclaimer</u>

•	Type of data	EEG
---	--------------	-----

Subjects18

Sampling frequency 512Hz

• Length ≒ **582s**

Sampling points **297896** (512×581.8281)


Channels **64 (10-20 system)**

Preprocessing ICA - Artifacts Removing


Filtering - 0.5Hz Low-pass, 50Hz High-pass

Experiment

<Standard Visual Oddball Task>



ERP components in Visual Oddball Task




A <u>frontro-central N2 component of ERP</u> is primarily affected by perceptual novelty, whereas only the <u>centro-parietal P3 component</u> is modulated by both stimulus significance and novelty.

ERP components in Visual Oddball Task



A frontro-central N2 component of ERP is primarily affected by perceptual novelty, whereas only the centro-parietal P3 component is modulated by both stimulus significance and novelty.


EEG channel (electrode)



ERP (Event Related Potential)

ERP(사건관련전위)

: 실험자가 피험자에게 가한 Event(자극)에 대해서 발생한 뇌파(EEG)



Name

Positive peak voltage : P Negative peak voltage : N

Sequence: P1, P2, P3... / N1, N2, N3...

Timing: P300, N170, N400 ...

Waveform

- 1 Peak voltage amplitude
- 2 Latency
- Absolute latency

time interval between stimulus presentation and the point of maximal value (peak) of a defined component

- Relative latency (inter-peak latency) time interval between two components
 - 3 Event code (=Trigger code)

MATLAB 실습

